



Changing accessories with your new FEIN MULTIMASTER's QuickIN system

FEIN. Powered by
innovation.



1. Grasp the tool body firmly and lift the quick change lever with your other hand.




2. Support the tool on a solid surface if necessary. Be sure the lever is fully open.



3. Remove the holding pin.



4. Position the accessory (pad or blade) on the spindle (remember, accessories can be placed at different angles).



5. Push the holding pin into place while holding the accessory in the desired position. **Listen for the "CLICK"**.



6. Close the "QuickIN" lever completely.





Using your new FEIN MultiMASTER

FEIN. Powered by
innovation.



CORRECT

Always cut with a smooth back and forth motion to keep the cut line clear. Never force the blade. Apply light pressure only to guide tool.



INCORRECT

Do not twist the tool while cutting. This can cause the blade to bind.



CORRECT

When cutting into a corner, turn the flat side of the blade away from the area you want to cut.



CORRECT

Sand with a smooth back and forth motion, allowing the weight of the tool to do the work.



INCORRECT

Avoid sanding with only the tip of the pad. Keep as much sandpaper in touch with the work surface as possible.



CORRECT

Always sand with the pad and sandpaper flat against the work surface. Work smoothly in a back and forth motion.



INCORRECT

Avoid tipping the pad. Always sand flat.

MADE IN GERMANY

3 41 10 119 21 0